

Filter Replacement

Prompt filter replacement will prevent any potential damage to your Defender® that may result from its continued operation with a clogged filter condition.

To Replace your Filter(s):



1. After unplugging the Defender®, place the unit on its side and remove the retaining nut on the bottom of the unit by turning counterclockwise. Return the unit to its upright position and lift off the top motor assembly.



2. Return the unit to its upright position and lift off the top motor assembly.



3. Remove the Medi-Filter® Cartridge and Enviropure® Charcoal Filter. If only replacing the Enviropure® Charcoal Filter, remove the old charcoal filter from the Medi-Filter® Cartridge and discard it.

Note: The charcoal filter is fastened with velcro.



4. Place the new Enviropure® Charcoal Filter around the outside of the Medi-Filter® Cartridge and fasten with the velcro. If also replacing the Medi-Filter® Cartridge, fasten the new Enviropure® Charcoal Filter to the new Medi-Filter® Cartridge. Return the filters to the unit.



5. Replace the top motor assembly.



6. Place the unit on its side to secure the retaining nut on the bottom of the unit. Return the unit to its upright position to resume use.